



## Finish Dishwasher Cleaner – 250ml

**Variant code: 04-457**

A dirty dishwasher won't give you the sparkling results you're looking for. Most people don't realise that grease and limescale can build up in the vital parts of your dishwasher.

Finish Dishwasher Cleaner removes the grease and limescale, even in the hidden parts, leaving your machine sparkling clean and smelling fresh.

A cleaner dishwasher means cleaner dishes.

Property	Value
Fragrance	Lemon
Dilution	Use Neat
pH	1.3
Area of Use	Automatic dishwashers
CLP	corrosive
How to Use	Empty dishwasher. Remove tab from bottle, invert and place in bottom drawer of dishwasher, complete washing cycle as normal.
Chemical Colour	Yellow