



Finish Powerball Dishwasher Tablets - Pack of 100

Variant code: 04-454

#1 Recommended by renowned dishwasher manufacturers. X2 Power actions – powerful clean, tea stain removal with Finish classic pre-soaking action.

The powerball soaks and softens tough food stains and powerful detergents lift off and wash away all traces of food.

Property	Value
Fragrance	Fragrant
рН	10.5
Area of Use	Dishwashers
CLP	irritant
How to Use	Place one tablet in dispenser prior to starting dishwash cycle
Chemical Colour	Red, white & Blue