



Finish Rinse Aid – 400ml

Variant code: 04-456

Finish Shine & Dry Rinse Aid helps deliver sparkling dishes and cutlery every time.

The rinse aid contains a quick dry formula to provide a clean and shiny finish to your dishes, leaving them sparkling. Finish Rinse Aid works in the rinse cycle to thoroughly remove detergent and food residues that can otherwise leave spots and stains.

- Finish rinse aid for domestic and professional use
- Contains quick dry formula
- Thoroughly cleans away food residues
- Works to remove remaining detergent
- Ideal for restaurants and any other catering environment

Property	Value
Fragrance	Characteristic
pH	2.8
Area of Use	Automatic dishwashers
CLP	irritant
Chemical Colour	Blue