



Griddle Screens – Pack of 10

Variant code: 12-200

The abrasive screen makes light work of burnt on food, drawing up grease into the pad. It's part of the Griddle Cleaning Kit that's made up of three parts: a plastic or metal holder to avoid direct contact with hot surfaces; the thick griddle pad, which absorbs dirt and grease; and the abrasive screen to easily remove burnt-on food and grease from flat griddles and hot plates.