



Windmill Kettle and Shower Head Descaler – 500ml

Variant code: 04-344

Fast acting, non toxic – Removes limescale, dirt and stains.

For the descaling of metal and plastic appliances such as kettles, irons and shower heads – NOT suitable for use on enamel or marble surfaces.

Property	Value
Fragrance	Odourless
pH	2
Dilution	125ml for kettles. 125ml in 350ml warm water solution for shower heads.
Area of Use	Kettles and Shower Heads
CLP	corrosive
How to Use	Kettle: Fill with warm water, add descaler. Never switch on/heat kettle. Wait until fizzing ceases or at least 4 hrs. Repeat if required. Refill, boil, then empty/rinse thoroughly. Shower head: Soak in solution until scale goes, rinse shower head/bowl
Chemical Colour	Clear