



## Windmill Kettle and Shower Head Descaler – 500ml

**Variant code: 04-344**

**Windmill Kettle and Shower Head Descaler** is a fast-acting cleaning solution designed to remove **limescale, dirt and staining** from a variety of household and commercial appliances. As part of the Windmill professional cleaning range, it delivers reliable descaling performance while maintaining ease of use and safety across routine maintenance applications.

Formulated to be **fast acting and non-toxic**, the descaler effectively breaks down limescale deposits that build up over time in water-based appliances. This helps restore efficiency and performance while improving the overall cleanliness and lifespan of equipment. The formulation is suitable for use on both **metal and plastic appliances**, making it a versatile solution for everyday descaling needs.

Designed specifically for appliances such as **kettles, irons and shower heads**, the product targets areas where mineral deposits commonly accumulate. It removes scale, dirt and associated stains without the need for excessive scrubbing, simplifying maintenance routines. However, it is **not suitable for use on enamel or marble surfaces**, ensuring correct application is followed to maintain surface integrity.

Supplied in a **500ml format**, it is ideal for regular maintenance use in both domestic and professional environments, providing an effective and convenient descaling solution.

---

### Product Features

- Fast-acting **appliance descaler**
- Removes **limescale, dirt and stains**
- Suitable for **metal and plastic appliances**
- **Non-toxic formulation** for safer use
- Effective on **kettles, irons and shower heads**
- Easy application for routine maintenance

---

### Product Benefits

- Restores appliance efficiency by removing limescale build-up

- Reduces maintenance effort with fast-acting performance
- Helps prolong the lifespan of appliances
- Suitable for a range of common descaling tasks
- Provides reliable and consistent cleaning results
- Supports regular hygiene and maintenance routines

---

## Technical Characteristics

- Suitable for **descaling metal and plastic appliances**
- Not suitable for use on **enamel or marble surfaces**
- Designed for targeted application on limescale deposits
- Fast-acting formulation for efficient cleaning
- Compatible with standard manual cleaning methods
- Requires use in accordance with manufacturer guidelines

---

## Applications

Windmill Kettle and Shower Head Descaler is suitable for use in **domestic, commercial and hospitality environments**, including kitchens, staff facilities and washrooms. It is particularly effective for maintaining **kettles, irons and shower heads**, where limescale build-up can affect performance and hygiene. Its fast-acting and easy-to-use formulation makes it ideal for routine maintenance in both low and high-use environments.

Property	Value
Fragrance	Odourless
pH	2
Dilution	125ml for kettles. 125ml in 350ml warm water solution for shower heads.
Area of Use	Kettles and Shower Heads
CLP	corrosive
How to Use	Add 125 ml of descaler to warm water, soak kettles without heating for at least 4 hours (then rinse, boil clean water, and rinse again) and soak shower heads until limescale is removed before rinsing thoroughly.
Chemical Colour	Clear

**Property****Value**

Kettles

Fill the kettle with warm water and add 125ml of descaler. Do not switch on or heat the kettle. Wait until fizzing stops or for at least 4 hours. If scale persists, repeat action. Empty kettle. Refill with clean water and boil. Empty and rinse.

Shower Heads

Fill a bowl with warm water and add 125ml of descaler. Immerse shower head in the solution until the scale has gone. Rinse both shower head and bowl before re-use.