



## Windmill Highly Concentrated Machine Dishwasher Detergent – 20L

**Variant code: 04-815**

Automated dishwash detergent for high soil and low tannin levels Active de-foamers work in the toughest of conditions, whilst progressive corrosion inhibitors protect dishwasher parts.

Suitable for most types of dishwashing machines

How to use:

Remove food scraps from dishes before racking. Normally a concentration of 0.05% – 0.50% (500ppm – 5000ppm) is used dependent on level of soiling and water hardness. The temperature of the wash cycle should be at least 60°C.

NB DO NOT USE on Aluminium, Lead crystal or hand painted china. PROTECT FROM FROST

Property	Value
Fragrance	Odourless
Dilution	Normally a concentration of 0.05% – 0.50% (500ppm – 5000ppm) is used dependent on level of soiling and water hardness.
pH	13.5
Area of Use	Dishwashers
CLP	corrosive
How to Use	Remove food scraps from dishes before racking. The temperature of the wash cycle should be at least 60°C.
Chemical Colour	Amber