

Code: 06-565

**Windmill Eliminator Max**  
AUK Supplies Ltd

**Laboratory Test Results**

Microorganism	Classification	Test Method	Tested by	Test Temperature	Contact time	Conditions	Dilution	Result (Reduction)
<i>Escherichia coli</i> NCIMB 8879 <i>Staphylococcus aureus</i> NCIMB 9518 <i>Enterococcus hirae</i> NCIMB 8192 <i>Pseudomonas aeruginosa</i> NCIMB 10421	Bacteria	BS EN 1276:2019	Internal UKAS	20°C	30 seconds	Dirty 3g/L BSA	Neat	PASS (>5lg)
<i>Candida albicans</i> NCPF 3179	Yeast	BS EN 1650:2019	Internal UKAS	20°C	30 seconds	Dirty 3g/L BSA	Neat	PASS (>4lg)
<i>Vaccinia virus</i> VR-1549 Elstree strain* <sup>1</sup>	Enveloped virus	BS EN 14476:2013 + A2:2019	External UKAS	20°C	1 minute	Dirty 3g/L BSA + 3ml/L sheep erythrocytes	Neat	PASS (>4lg)
<i>Murine norovirus (s99)</i>	Non enveloped virus	BS EN 14476:2013 + A2:2019	External UKAS	20°C	5 minutes	Clean (0.3g/L BSA)	Neat	PASS (>4lg)
<i>Staphylococcus aureus</i> NCIMB 9518 <i>Enterococcus hirae</i> NCIMB 8192 <i>Pseudomonas aeruginosa</i> NCIMB 10421	Bacteria	BS EN 13727:2012 + A2:2015	Internal UKAS	20°C	30 seconds	Dirty 3g/L BSA + 3ml/L sheep erythrocytes	Neat	PASS (>5lg)

Microorganism	Classification	Test Method	Tested by	Test Temperature	Contact time	Conditions	Dilution	Result (Reduction)
<i>Legionella pneumophila</i> ATCC 33152	Bacteria	PN-EN 1276:2019	External PCA	20°C	5 minutes	Dirty (3g/L BSA)	Neat	PASS (>5lg)

\*1 This product therefore is effective against all enveloped viruses as defined in EN 14476:2013 + A2:2019 Annex A. This therefore includes all coronaviruses and SARS-CoV-2.